



Arrows indicate direction of flow; R--residual hydrant; F--flow hydrant.

Figure 6-2. Suggested flow-test locations.

SOURCE

American Water Works Association Manual M17,
 "Installation, Field Testing, and Maintenance of Fire
 Hydrants."